



Advanced Technology  
INTERNATIONAL

**MAKE SURE YOUR FIREARM IS UNLOADED  
BEFORE STARTING**




**SHOTSHELL HOLDER INSTALLATION INSTRUCTIONS**

PART#SHO0500

**Installation Instructions**

- 1.) Cut out mounting template.
- 2.) Place five shotgun shells in holder and position on stock.
- 3.) Locate proper position on stock so there is no interference with cheek, shoulder, etc.
- NOTE:** Shotshell Holder may be mounted on either side of the stock.
- 4.) Place mounting template where you wish to mount the Holder and tape it down.
- 5.) Mark **ONLY** the corner holes of the template with a sharp object  
i.e. nail, punch awl
- 6.) Remove the shells and drill the four holes using a 7/64" drill bit.
- 7.) Mount Shell Holder using the four flathead screws supplied. Re-insert all five shotshells and check for a "snug" fit.
- NOTE:** For tighter fit, install middle 2 screws



**SHOTSHELL HOLDER INSTALLATION INSTRUCTIONS**  
PART#SHO0500

[www.ATIgunstocks.com](http://www.ATIgunstocks.com)

Advanced Technology International  
2733 West Carmen Avenue  
Milwaukee, WI 53229  
800.925.2322