



## T3 Adjustable TactLite Shotgun Stock Modification for Winchester SXP with New Trigger Assembly



### Warning:

When handling a firearm, always follow the proper handling procedures at all times. Failure to follow these procedures could result in serious damage, injury, or death. WE are not responsible for damage to property, injury, or death resulting from improper installation, misuse or modification of products. If you are not comfortable completing any of the following steps, or do not have the proper tools enlist the help of your local gunsmith. We are not responsible for components that are damaged due to improper installation.

### SXP Adapter Modification for new Trigger Assembly

Figure 1a



If your SXP has the new trigger assembly as seen in (Figure 1a) a small modification will need to be made to the SXP adapter before installing.

Figure 1b



Figure 1c



Take your SXP adapter as seen in (Figure 1b) and using a file or dremel, remove a small amount of material from the bottom of the mount as seen in (Figure 1c). Make sure to only remove a small amount at a time and then test fitment.

Figure 1d



Once you have removed the material, test fit the adapter to the receiver as seen in (Figure 1d) to make sure you have a flush fit. You can then continue with Step 4 of your installation instructions.