

PRODUCT INSTALLATION GUIDE

TactLite Scorpion Razorback Recoil Pad Upgrade Kit



HARDWARE INCLUDED

[2] #8 x 48-2 x 1/2" Torx Head Plastite Screw

TOOLS NEEDED

Torx Driver



Warning: When handling a firearm, always follow the proper handling procedures at all times. Failure to follow these procedures could result in serious damage, injury, or death. We are not responsible for damage to property, injury, or death resulting from improper installation, misuse or modification of products. If you are not comfortable completing any of the following steps, or do not have the proper tools enlist the help of your local gunsmith. We are not responsible for components that are damaged due to improper installation.



1

Using a T20 Torx driver remove the 2 screws from the existing recoil pad as seen in Figure 1.

NOTE: Make sure to keep the screws as you will use them to install the pad plate.



4

Using the screws from figure 1 and a T20 Torx driver, tighten the buttstock plate to the TactLite Stock as seen in Figure 4.



2

Next, remove the existing recoil pad from the TactLite stock as seen in Figure 2.



5

Place the Scorpion Recoil Pad onto the buttstock and using the provided #8 x 48-2 x 1/2" Torx Head Plastite Screws and a T20 Torx driver tighten to the TactLite stock as seen in Figure 5.



3

Take the buttstock plate as seen in Figure 3 and place onto the rear of the TactLite stock making sure to line up the screw holes.



6

To install the Razorback Recoil Pad on the Strikeforce stock, place the buttpad on the rear of the buttstock (do not use the plate that was included in the kit) and using a T-20 torx driver install the provided (2) 8 x 48-2 x 1/2" Plastite Torx Head Screws until snug as seen in Figure 6.